INSTRUCTION MANUAL

TRASHCAN FOLDABLE

bo-camp

5329979

Step 1

Open the bucket, and take out the pedal and strip from the bucket.





Step 2

Close the button on the lid





Step 3

Fix the strip on the edge of the bucket, and put the plastic bag inside of bucket if needed





Step 4

Fix the bucket on the pedal



