




INSTRUCTION MANUAL

FLOOR LAMP HARTER

5818868



Press and hold for five seconds to enter the timing function and the light will be closed after 2 hours

Charging

Red light: charging (not full)
Green light: full