

INSTRUCTION MANUAL

TABLE LANTERN LUCERNE




Before operating

Please read these instructions before operating this lantern.

Specification of lantern

- product size: (dia)12.7cm x (H)21.4cm
 - product material: ABS/GPPS
 - Tungsten LEDt: 4pcs (1w)
 - SMD bulb: 4pcs(0.5w)
 - Battery: 3.7v/4000mAh(Lithium rechargeable)
 - Lighting mode: 0%~100% dimmer switch
 - Metal handle on top for easy transportation
-
- Type-A interface can charge other items,green indicator on
 - Type-C interface can charge itself,red indicator flashes
 - Green indicator always on when fully charged
 - Dimmer switch button located on the center of lantern



Warning

- 1) Before using the lantern for the first time, fully charged 8 hours at least
- 2) Make sure to turn off the lantern before recharging
- 3) Only use the USB charging cable provided to charge the lantern
- 4) Only charge in a cool well ventilated area
- 5) When not in use,ensure that the battery is recharged at least every 6 months
- 6) Keep away from direct sunlight, and store in a cool place with low humidity