

# INSTRUCTION MANUAL

## CHILD'S CHAIR

1204776



**IMPORTANT!** READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

### General Instructions for Safe Use

ENG: Thank you for choosing our seating product. To ensure the safety of your child, please read and follow these instructions carefully before use.

### WARNING

ENG: DO NOT place this product near a window. It can be used as a step by the child, leading to a risk of falling out of the window. Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product. DO NOT place this product near a window where cords from blinds or curtains could strangle a child.

### WARNING

- Document Details**  
Document Number: xxx  
Date of Issue: xxx
- Importer Information**  
Importer: VAHB B.V.  
European Address: Burgemeester Krollaan 4  
5126 PT Gilze, The Netherlands  
Website: BO-CAMP.COM
- Product Identification**  
Name: Child's chair  
Trade mark: BO-CAMP  
Model Number: Item1204776
- Intended Age Group**  
This seating is intended for children aged xxx
- Product Maintenance**  
DO NOT use the seating if any part is broken, torn, or missing.  
Use only spare parts approved by the manufacturer.  
DO NOT wash, wipe clean ONLY.
- Product Assembly**  
Unfold the chair and lock the cross bar for security.

### Contact information

ENG: For further assistance or inquiries, please contact:  
Customer Service:  
VAHB B.V.  
Burgemeester Krollaan 4  
5126 PT Gilze, The Netherlands

