










INSTRUCTION MANUAL

CUPBOARD COOPER

1609305



 ax4	 bx5	 cx4	 dx4	 ex1	 fx1
 gx1					
 Ax1  Bx1  Cx2  Dx2  Ex2  Fx1  Gx2  Hx1					
1 			2 		


INSTRUCTION MANUAL

CUPBOARD COOPER


1609305




3



4



5



6

